

Always
check pattern
BEFORE
leaving the shop!

1. Check pattern in shop **FIRST!**



2. Tape one edge of the template to surface with masking tape and unroll it. Level the template and tape the other edge to the installation surface



3. Mark holes with center punch, then drill 1/4" holes 3" deep where indicated on your template. Remove the template and clean out all drill holes using any of